

English

VISION:elite™ 5M Pixel Color Gig-E Camera VCC-F60FV19GE

Product Specification & Operational Manual

CIS Corporation

Table of Contents

1.	Sco	ppe of Application	3
2.	Har	ndling Precautions	3
3.	Pro	duct Outline	4
4.	Spe	ecification	5
4	l.1.	General Specification	5
4	l.2.	Camera Output Signal Specification	7
4	l.3.	CCD Spectral Response (Representative Value)	8
2	l.4.	Image output format (Coyote Application Setting)	
5.	Fur	nction Settings	9
6.	Ext	ernal Connector Pin Assignment	11
6	5.1.	12 pins Circular Connector HR10-10R-12PA (HIROSE)	11
6	5.2.		
7.	Tim	ning Chart	13
7	' .1.	Horizontal Synchronous Signals Timing	13
7	⁷ .2.	Full Frame Scan Mode Timing	13
7	7 .3.	Standard Trigger Mode Timing	14
7	⁷ .4.	Pulse Width Trigger Timing	
8.		tial Scan Mode Details	
9.	Rer	mote Interface Function	17
10.	In	itial Settings	18
11.		CD Optical Axis Accuracy	
12.		imensions	
13.	Ca	ases for Indemnity (Limited Warranty)	22
14.		CD Pixel Defect	
15.	Pr	oduct Support	23

Scope of Application

This is to describe VCC-F60FV19GE, 5M pixels Gig-E Color CCD Camera. All specifications contained herein are subject to change without prior notice. Reproduction in whole or in part is prohibited.

2. Handling Precautions


The camera must not be used for any nuclear equipments or aerospace equipments with which mechanical failure or malfunction could result in serious bodily injury or loss of human life. Our warranty does not apply to damages or defects caused by irregular and/or abnormal use of the product.

Please observe all warnings and cautions stated below.

Our warranty does not apply to damages or malfunctions caused by neglecting these precautions.

- Do not use or store the camera in the following extreme conditions:
 - > Extremely dusty or humid places.
 - \triangleright Extremely hot or cold places (operating temperature -5°C to +40°C)
 - Close to generators of powerful electromagnetic radiation such as radio or TV transmitters.
 - Places subject to fluorescent light reflections.
 - Places subject to unstable (flickering, etc.) lighting conditions.
 - > Places subject to strong vibration.
- Remove dust or dirt on the surface of the lens with a blower.
- Do not apply excessive force or static electricity that could damage the camera.
- Do not shoot direct images that are extremely bright (e.g., light source, sun, etc.), and when camera is not in use, put the lens cap on.
- Follow the instructions in Chapter 6, "External connector pin assignment" for connecting the camera. Improper connection may cause damages not only to the camera but also to the connected devices.
- Confirm the mutual ground potential carefully and then connect the camera to monitors or computers. AC leaks from the connected devices may cause damages or destroy the camera.
- Do not apply excessive voltage.(Use only the specified voltage.) Unstable or improper power supply voltage may cause damages or malfunction of the camera.
- The voltage ripple of camera power DC +12V \pm 10% shall be within \pm 50mV. Improper power supply voltage may cause noises on the video signals.
- The rising time of camera power supply voltage shall be less than +10V, Max 60ms. Please avoide noises like chattering when rising.

2ch output, separated into right and left, CCD is utilized for VCC-F60FV19GE. Image signals for right half screen and left half screen are output via each independent circuit. Therefore, differences between right screen and left screen could be seen depending on the usage conditions (shooting conditions /temeperature conditions and so on). CIS trys its best to adjust this differences but please be noted it would not be perfect.



In case of abnormal operation, contact the distributor from whom you purchased the product.

Product Outline

VCC-F60FV19GE is a Gigabit Ethernet interfaced, high-resolution industrial color (RAW) video camera module utilizing a 2/3 type PS IT CCD. 5M pixels CCD image sensor with on-chip micro-lenses realizes high sensitivity and high resolution. At Full Frame Scan Mode, entire pixels can be read out within approx. 1/15s.

Features

- ☐ High speed communication, maximum 108MB/s. (Comform to 1000BASE-T)
- ☐ The maximum transmission distance is approx. 100m with cable more than CAT5e.
- ☐ Camera settings can be set via LAN.
- □ Software trigger input via LAN or hardware trigger input via 12pin connector at rear is selectable.
- \square Shutter speed can be set from 1/15sec \sim 1/30,000sec by 1H.
- At partial scan mode, both capturing start position and capturing width can be set by 3H.

Bundled Items

- □ Camera
- ☐ iPORT Software Development Kit 2.4.1 build 921. ※
- ☐ Gig-E Camera Control Software (CamCtlSetup.exe) ※
- ☐ Start up manual
- Please ask for the details or download it from our web.

©2010 CIS Corporation. All rights reserved.

4. Specification

4.1. General Specification


Item		Specification			
Pickup device	Device Type	2/3 type Interline Transfer color CCD, Sony ICX625AQA			
	Effective Pixel Number	2456 (H) x 2058 (V)			
	Unit Cell Size	3.45 μ m (H) x 3.45 μ m (V)			
	Chip Size	9.93mm (H) x 8.70mm (V)			
Videooutput frequency	Pixel Clock	60 MHz			
	Horizontal Frequency	31.185 KHz Pixel Clock: 1924CLK			
	Vertical Frequency	approx 15.000Hz Full Frame Scan Mode: 2079H			
Sync. system	Internal Sync. System				
Video output standard	Gigabit Ethernet (Comfo	orm to 1000BASE-T) Trasferring speed: 108MB/s (max)			
Resolution	1600 TV lines (Coyote A	Application Bayer Viewer: RGB Convert)			
Resolving power	RAW 8bit / 10bit (Note;	Real time output is invalid at 10 bit output.)			
Sensitivity	F 8.0 2000 lx (Shutter speed 1/15s, Gain 0dB)				
Minimum illumination	F 1.4 15 lx (Shutter speed 1/15s, Gain Max +18dB)				
Dust or stains in	No dust or stain shall be detected on the testing screen with setting the camera				
optical system	aperture at F16.				
Power requirements	DC +12V \pm 10% (Max	voltage not to exceed +15V)			
Power consumption	5.8 W (At DC +12V IN,	normal mode, and full frame scan mode)			
	6.0W (At DC +12V IN, r	normal mode, and partial scan mode)			
Dimension	Refer to overall dimensi	on drawing (Clause 12)			
	55mm x 55mm x 60mr	n (excluding projection)			
Mass	Approx. 190 g				
Lens mount	C mount (Refer to overa	all dimension drawing)			
Optical axis accuracy	Refer to drawing for CC	D Optical Axis Accuracy (Clause 11)			
Gain variable range	$0\sim$ +12dB (Analog Gain; over 0dB \sim +6dB, Digital Gain; 0dB \sim +6dB)				
White balance	2800K~9000K				
adjustment range	(guaranteed range)				
Shutter speed	1/15s (Off) \sim 1/30000s				
variable range					
Trigger shutter mode	 Standard Trigger Mod 	le · Pulse Width Trigger Mode			

Item		Specification				
Safety/Quality	//Quality UL: Conform to UL Standard including materials and others.					
standards	RoHS: Conform	m to RoHS				
	CE: EN55022	:2006 (Class A) for Emission				
	EN61000	-6-2:2005 for Immunit	cy .			
	FCC: To be ap	plied to FCC Class A di	gital Device			
	This device co	mplies with Part 15 of	the FCC Rules. Operation is subject to the			
	following two o	conditions: (1) this devi	ice may not cause harmful interference, and			
	(2) this device	must accept any interf	erence received, including interference that			
	may cause und	desired operation.				
		Acceleration	98 m/s ² (10.0G)			
	Vibration	Frequency	20∼200 Hz			
Durability	VIDIALIOII	Direction	XYZ 3 directions			
Durability		Testing time	120 min for each direction			
	Shock	No mulfunction shall be occurred with 980m/s 2 (100G) for \pm X,				
		\pm Y, and \pm Z, 6 directions. (without package)				
	Temperature	Performance guaranteed temperature: $0^{\circ}\text{C} \sim +40^{\circ}\text{C}$				
		Camera operation guaranteed temeprature: -5 $^{\circ}$ C $^{\circ}$ +40 $^{\circ}$ C				
		lpha All the specifications specified in this manual is guaranteed				
Operation environment		under performance guaranteed temperature.				
		%All the camera functions operate normally under operation				
		guaranteed temperature				
	Humidity	RH 20 \sim 80% with no condensation				
Storage environment	Temperature	-25°C ∼ +60°C				
Storage environment	Humidity	RH 20~80% with no condensation				
	LAN Card	Intel PRO/1000 series	3			
	LAN Cable	MOD-YSP-A1AS-SP series (Honda Tsushin Kogyo)				
Recommended System		MV series (CEI)				
	OS	Windows XP, Windows VISTA				
	Memory	Over 512 MB (over 10	GB recommeded)			

4.2. Camera Output Signal Specification

	Item	Specification				
Video output		2456 (H) x 2058	(V)	At Full Frame Scan Mode		
data	Video out	60MHz 2Tap outp	out			
	LVAL output	LVTTL (3.3V Outp	put)	HR10-10R-12PA		
	FVAL output	LVTTL (3.3V Outp	put)	※ Output pin assignment is		
Sync. Signal	DVAL output	LVTTL (3.3V Outp	put)	set via iPort SDK. Please		
I/O	SP (Exposure Pulse)	LVTTL (3.3V Outp	put)	refer to our VCC-G60/F60		
				GE series startup manual,		
		section 5.7. Trigger Mode.				
	Polarity	POSI/NEGA Sele				
Trigger input	Trigger Pulse width	Min. over 2 HD ~	\sim Max. under 4	158 HD		
Trigger input	Hardware Trigger input	LVTTL (5.0V Tole	erant)	HR10-10R-12PA		
	Software Trigger input		1	RJ-45		
	White Clip Level	Digital 8bit	: FFh			
	Setup Level	Digital 8bit	: 08h±04h			
Video output	Dark Shading	Digital 8bit	: Under 08h fo	r both horizontal and vertical		
signal			(Conditions: Ga	ain 0dB)		
	Leval differences	Digital 8 bit	· Under 03h (C	Conditions: Gain 0dB)		
	between right and left		. Grider USIT (C	Ti (Conditions, Gain Gab)		


5 secounds shall be waited after turning on power to get proper camera operation.



12 pins circular connector at rear GPIO interface ©2010 CIS Corporation. All rights reserved.


4.3. CCD Spectral Response (Representative Value)

* Lens charcteristics and luminous source charcteristics are not considered.



4.4. Image output format (Coyote Application Setting)

- · 2-Taps , Segmented, Dual Left + Right Inverted Output
- Area of interest Width: 2456 Height: 2058 Offset X: 0 Offset Y: 12
- Bayer Pattern RGGB



5. Function Settings

Camera functions can be set with serial communications.

Function	Address	Data	
		0:	0 dB: Analog Fixed Gain
		1:	+3 dB: Analog Fixed Gain
Gain	001	2:	+6 dB: Analog Fixed Gain
		3:	+12 dB: Analog Gain (+6dB) + Digital Gain (+6dB)
		4:	Manual Gain (Refer to Address 005, 006, 007, and 008)
		0:	1/15s(Off)
		1:	1/30s
		2:	1/60s
		3:	1/90s
		4:	1/120s
		5:	1/150s
		6:	1/200s
		7:	1/250s
E-Shutter	002	8:	1/500s
		9:	1/750s
		10:	1/1000s
		11:	1/2000s
		12:	1/5000s
		13:	1/10000s
		14:	1/15000s
		15:	1/30000s
		16:	Manual Shutter (Refer to Address 009 & 010)
		0:	THRU
		1:	3200K
White Balance	003	2:	Spare
	004	3:	Spare
		4:	Manual White Balance (Address 156, 157, 158 and 159)
		0:	Normal Mode (Trigger Mode Off)
Trigger Mode		1:	Standard Trigger Mode (Shutter speed can be set with address 002.)
		2:	Pulse Width Trigger Mode (Shutter speed can be set with trigger pulse width.)
Manual Analog Cain (Dight)	0058 006	0∼512:	0: 0dB~512: over +12dB (Log Linear)
Manual Analog Gain (Right)	005&006	0°~512:	% Set the address 001 data to 004.
Manual Analog Cain (Loft)	0078.000	0∼512:	0: $0dB\sim512$: over $+12dB$ (Log Linear)
Manual Analog Gain (Left)	007&008	U [*] 312.	% Set the address 001 data to 004.
			1/15s (Off)~1/36058s
			% Set the address 002 data to 016.
Manual Shutter Control	009&010	0~2078:	Address 009 MSB and address 010 LSB makes total 16 bit.
			Shutter speed = (2078-(009&010)) x 32.07 μ s + 27.73 μ s
			Max data = 2078
Trigger Polarity	011	0:	Positive Input
ggci i didility		1:	Negative Input
Output Data Select	013	0:	8bit Output Data
Julput Data Dolott		1:	10bit Output Data


Function	Address	Data		
Carrera Mada	014	0:	Gamma Off (1.0)	
Gamma Mode	014	1:	Gamma On	
Darkiel Cook Marks	015	0:	Full Frame Scan Mode	
Partial Scan Mode	015	1:	Partial Scan Mode	
			Set the address 015 data to 001.	
Darkiel Cook Chart Desition	0160017	0. 605.	Address 016 MSB and address 017 LSB makes total 16 bit.	
Partial Scan Start Position	016&017	0~685:	Start Position: 3 H/step Min Data: 0 (0H)/Max Data: 685 (2055 H)	
			Start Position (016&017)+ Effective Line (019&020) <= 685	
			Set the address 015 data to 001.	
Double Coop Effective Line	0100020	0 - 604	Address 019 MSB and address 020 LSB makes total 16 bit.	
Partial Scan Effective Line	019&020	U~68 4 :	Effective Line: 3 H /step Min Data: 0 (3 H)/Max Data: 685 (2058 H)	
			Start Position (016&017)+ Effective Line (019&020) <= 685	
Dartial Coop Tatal Line	021&022	0~2078:	Read Only	
Partial Scan Total Line		U~2078:	Total line number at Partial Scan Mode or Full Frame Scan Mode minus 1 is set	
Manual Digital Cain (Dight)	126&127	256 ~	256: x1(0dB)~512: x2(+6dB)	
Manual Digital Gain (Right)		512:	※ Set address 001 data to 004.	
Manual Digital Gain (Left)	128&129	256 ~	256: x1(0dB)~512: x2(+6dB)	
Manual Digital Gain (Left)		512:	※ Set address 001 data to 004.	
Manual White Balance R	156&157	256 ~	256: x1(0dB)~1023: x4(+12dB)	
(Right)		1023:	※ Set address 003 data to 004.	
Manual White Balance B	158&159	256 ~	256: x1(0dB)~1023: x4(+12dB)	
(Right)		1023:	Set address 003 data to 004.	
Manual White Balance R	1000.101	256 ~	256: x1(0dB)~1023: x4(+12dB)	
(Left)	180&181	1023:	※ Set address 003 data to 004.	
Manual White Balance B	182&183	256 ~	256: x1(0dB)~1023: x4(+12dB)	
(Left)	1020103	1023:	※ Set address 003 data to 004.	
Data Save	255	Input 083	or 053 to save the data in EEP-ROM.	

Note: When setting the data with 2 Byte, High Byte shall be set first, then Low Byte to the next. The camera rewrites the internal resister when receiving Low Byte.

6. External Connector Pin Assignment

6.1. 12 pins Circular Connector HR10-10R-12PA (HIROSE)

Pin		Signals which can be controlled by GigE
No.		Camera Control Software
1	GND	
2	Power In DC +12V	
3	TTL In3	Trigger Input
	(LVTTL Input 5V Tolerant)	
4	TTL Out2	LVAL, FVAL, DVAL ,SP(Exposure) Output
	(LVTTL 3.3V Output)	
5	GND	
6	TTL In2	Trigger Input
	(LVTTL input 5V Tolerant)	
7	TTL Out1	LVAL, FVAL, DVAL ,SP(Exposure) Output
	(LVTTL 3.3V Output)	
8	TTL In1	Trigger Input
	(LVTTL input 5V Tolerant)	
9	TTL Out0	LVAL, FVAL, DVAL ,SP(Exposure) Output
	(LVTTL 3.3V Output)	
10	TTL In0	Trigger Input
	(LVTTL Input 5V Tolerant)	
11	NC	
12	NC	




TTL In(a) a:0 \sim 3 · · · Trigger Input etc.

TTL Out(b) b:0 \sim 2 · · · LVAL, FVAL, DVAL, SP, Pulse Generator etc.

※ Pin assignment and functions can be set arbitrarily via iPORT software.

Please refer to iPORT.Software.Coyote.pdf in \forall Program Files \forall Pleora Technologies Inc \forall iPORT Software \forall Documentation.

6.2. RJ-45 Gigabit Ethernet Connector MOD-YSJ88DA03C-CN+ (HONDA TSUSHIN KOGYO CO., LTD)



LINK LED: Lighting-off · · · Unconnected to LAN

Lighting-on · · · Connected to LAN


Blinking · · · Transmitting the data

ACT LED: Lighting-off · · · · Unconnected or connected with 10Mbps/100Mbps


Lighting-on · · · Connected with 1000Mbps

7. Timing Chart

7.1. Horizontal Synchronous Signals Timing



7.2. Full Frame Scan Mode Timing




7.3. Standard Trigger Mode Timing


 $\hfill\Box$ Trigger operation is CLK sync, V-Sync Reset.

Delay time, from detecting the trigger edge to the start of exposure, is 1.40 μ s at RAW mode.

☐ Trigger input can be accepted even when the camera is outputting video signals. However, a shutter timing, to start the next video output before completion of transferring video output for the prior signals, can not be worked. To input trigger signals when the camera is outputting video signals for the prior signals, it shall be synchronized with the down edge of camera LVAL output.

☐ Trigger input during the execution of exposure (exposure time) shall be ignored. (Refer to the "G" below.)







7.4. Pulse Width Trigger Timing

☐ Trigger operation is CLK sync, V-Sync Reset.

Delay time, from detecting the trigger edge to the start of exposure, is 1.40 μ s. Delay time, from detecting the trigger edge to completion of exposure, is 29.13 μ s.

☐ Trigger input can be accepted even when the camera is outputting video signals. However, a shutter timing, to start the next video output before completion of transferring video output for the prior signals, can not be worked. Please refer to the "C" below. To input trigger signals when the camera is outputting video signals for the prior signals, it shall be synchronized with the down edge of camera LVAL output.






©2010 CIS Corporation. All rights reserved.

8. Partial Scan Mode Details

Capturing start position and capturing width can be set by 3H via LAN.



Reading out position register (Address 016 & 017): $0(0H) \sim 685(2055H)$ 3H/step Effective line register (Address 019 & 020): $0(3H) \sim 685(2058H)$ 3H/step Total line register (Address 021 & 022): 706Lines + (Effective line register \times 2) + 2 (Read Only)

Note: Reading out position and effective line shall meet the following condition.

Reading out position register + Effective line register = < 685

Otherwise, the value, 685 – reading out position register, will be set to the effective line register.

<Example 1> Conditions: Reading out position register (Address 016 & 017) = 000

		<u> </u>	
Effective line register	Effective Lines	Total Lines register	Frame rate
(Address 019&020)		+ 1 H	
0	3 H	709 H	44 fps
	•	•	•
159	480 H	1027 H	30 fps
	•	•	•
255	768 H	1219 H	26 fps
	•	•	
341	1026 H	1391 H	22 fps
	•	•	
399	1200 H	1507 H	21 fps
•	•	•	
685	2058 H	2079 H	15 fps

9. Remote Interface Function

Through LAN, the camera can be controlled.

(1) The settings for RS-232C

Baud rate : 9600bps
Data : 8bit
Stop bit : 1bit
Parity : None

XOn/XOff : Not controlled

(2) Control code

· The total control code is 14 bits, which conforms to ASCII code.

• The control code consists of camera No. process code, remote controller address, remote controller data, and CR. Execute Read/Write through PC, and the camera will reply the data.

1	2	3	4	5	6	7th Byte	8	9	10	11	12	13	14
Camera No.				Process code	Remote controller			Remote controller data			<u>CR</u>		
					address								
000000: fixed "R						"R" Read mode	Please refer to the			000~255			0 Dh
				"W" Write mode	address table of								
				"C" Camera mode	Section 5. Function								
						Setting	js.						

Camera No. is fixed with 6 bite numerical strings, "000000".

Process code

Input any one of R, W, or C to the process code.

R (read mode) is to read the data of remote controller address.

Please be noted to set any dummy data (000 \sim 255) to 11th \sim 13th, since a command shall consists of 14 bytes.

W (write mode) is to write the data to the remote controller address.

Please be noted that the data cannot be saved into EEPROM of the camera.

(Reboot the camera, and the data is reset to the initial setting.)

To save the data into EEPROM, please refer to Section 5. Function Settings.

C is the code to send the data back from the camera.

Note: Do not set code C when sending the data from PC side.

Remote controller address

Note: Do not write the data into the address other than specified, since it may cause the damages or malfunction of the camera.

Remote controller data

Set the decimal number ($000\sim255$) for the remote controller data. Please be noted to set any dummy data at read control mode.

CR

Be sure to input "CR" to confirm the end of the command.


※ Note: When setting the data with 2 Byte, High Byte shall be set first, then Low Byte to the next.


The camera rewrites the internal resister when receiving Low Byte.

10. Initial Settings

Function	Address	Data
Gain	001	0: 0dB
E-Shutter	002	0: 1/15s (Off)
White Balance	003	1: 3200K
Trigger Mode	004	0: Normal Mode (Trigger Mode Off)
Trigger Polarity	011	0: Positive Input
Output Data Select	013	0: 8 bit Output Data
Partial Scan Mode	015	0: Full Frame Scan Mode
Partial Scan Total Lines	021 & 022	2078: Read Only

11. CCD Optical Axis Accuracy






?)Dimension from datum plane to the center of lens mouont.

910-003-00-00

(Unit:mm)


12. Dimensions



^{*1)} C Mount screws comply with ANSI/ASME B1.1, 1-32UN(2B).

999-500-00-00(1/2) (Unit:mm)

^{*2)} Screw length from C mount lens surface shall be under 6mm. And protruding portion shall be lesss than 10mm.



Cable Reference Drawing

999-500-00-00(2/2) (Unit:mm)

13. Cases for Indemnity (Limited Warranty)

We shall be exempted from taking responsibility and held harmless for damage or losses incurred by the user in the following cases.

- ♦ In case damage or losses are caused by fire, earthquake, or other acts of God, acts by third party, deliberate or accidental misuse by the user, or use under extreme operating conditions.
- In case indirect, additional, consequential damages (loss of business interests, suspension of business activities) are incurred as result of malfunction or non-function of the equipment, we shall be exempted from responsibility for such damages.
- In case damage or losses are caused by failure to observe the information contained in the instructions in this product specification & operation manual.
- In case damage or losses are caused by use contrary to the instructions in this product specification & operation manual.
- In case damage or losses are caused by malfunction or other problems resulting from use of equipment or software that is not specified.
- In case damage or losses are caused by repair or modification conducted by the customer or any unauthorized third party (such as an unauthorized service representative).
- Expenses we bear on this product shall be limited to the individual price of the product.

14. CCD Pixel Defect

CIS compensates the noticeable CCD pixel defects found at the shipping inspection prior to our shipment. On very rare occasions, however, CCD pixel defects might be noted with time of usage of the products. Cause of the CCD pixel defects is the characteristic phenomenon of CCD itself and CIS is exempted from taking any responsibilities for them.

Should you have any questions on CCD pixel defects compensation, please contact us.

15. Product Support

When defects or malfunction of our products occur, and if you would like us to investigate on the cause and repair, please contact your distributors you purchased from to consult and coordinate.